

Embedded antenna installation guide

1. Antenna attach on metal plane by screw (drop test)
2. Antenna attach on metal plane by conductive tape
 - metal plane size more than 25mm x 25mm (625mm²)
 - the distance between antenna radiator and plastic cover is 1mm - 2mm

