

Support Navilock

If you have further questions, please contact our customer support support@navilock.de

You can find current product information on our homepage: www.navilock.com

Final clause

Information and data contained in this manual are subject to change without notice in advance. Errors and misprints excepted.

Copyright

No part of this user manual may be reproduced, or transmitted for any purpose, regardless in which way or by any means, electronically or mechanically, without explicit written approval of Navilock.

Edition: 11/2022



User manual



Bedienungsanleitung



NAVILOCK®

Laptop Security Cable for USB Type-A port



EU Import: Tragant Handels- und Beteiligungs GmbH
Beeskowdamm 13/15, 14167 Berlin, Germany



Product-No: 20917
User manual no: 20917-a
www.navilock.com



English

System requirements

- USB Type-A port on the device

Package content

- Laptop security lock
- 2 x keys
- User manual

Safety instructions

This laptop lock is intended for use on USB sockets according to USB specification. The function may be restricted in the case of special designs of USB socket.

Lay the cable of the laptop lock so that it does not pose a trip hazard or block escape routes. We strongly recommend to notice the changed combination and keeping it in a safe place.

Disclaimer

Navilock assumes no liability or warranty for damages resulting from improper installation, assembly or use of the product or failure to comply with the operating instructions and/or safety instructions. Navilock is also not liable for any consequential costs resulting from loss/forgetting the number combination.

The USB port on the devices is sensitive and can be damaged if the lock is pulled. We do not assume any liability or warranty for this either.

Installation

1. Tie the cable around an object, such as a table leg, and pass the lock through the loop.
2. Insert the lock into the existing USB Type-A socket and press the button at the rear end. Please pay attention to the correct direction, otherwise the mechanism will not engage (see illustration).
3. Now the lock is locked.
4. The enclosed key is only needed to unlock the lock.



Deutsch

Systemvoraussetzungen

- USB Typ-A Port am Gerät

Packungsinhalt

- Notebook Sicherungskabel
- 2 x Schlüssel
- Bedienungsanleitung

Sicherheitshinweise

Dieses Notebookschloss ist zur Verwendung an USB-Buchsen nach USB-Spezifikation vorgesehen. Bei Sonderbauformen der USB-Buchse kann die Funktion eingeschränkt sein.

Verlegen Sie das Kabel des Notebookschlusses so, dass es keine Stolpergefahr darstellt oder Fluchtwege blockiert.

Wir empfehlen ausdrücklich, die geänderte Kombination zu notieren und an einem sicheren Ort zu verwahren.

Haftungsausschluss

Navilock übernimmt keinerlei Haftung oder Gewährleistung für Schäden, die aus unsachgemäßer Installation, Montage oder unsachgemäßem Gebrauch des Produktes oder einer Nichtbeachtung der Bedienungsanleitung und/oder der Sicherheitshinweise resultieren. Navilock haftet auch nicht für Folgekosten, die durch Verlust/Vergessen der Zahlenkombination entstehen.

Die USB Buchse bei den Geräten ist empfindlich und kann beschädigt werden, wenn am Schloss gezogen wird. Auch hierfür übernehmen wir keinerlei Haftung oder Gewährleistung.

Installation

1. Binden Sie das Kabel um einen Gegenstand, wie z. B. Tischbein und führen Sie das Schloss durch die Schlaufe.
2. Stecken Sie das Schloss in die vorhandene USB Typ-A Buchse und drücken Sie den Knopf am hinteren Ende. Achten Sie bitte auf die korrekte Richtung, da der Mechanismus sonst nicht greift (siehe Abbildung).
3. Nun ist das Schloss verriegelt.
4. Der beiliegende Schlüssel wird nur zum Entriegeln des Schlosses benötigt.